Group Members							
Name Userid Name Userid							
Lara Janecka	20460089 lajaneck	Tyler Babran	20457511 tbabran				

By filling out the names above, the group members acknowledge that a) they have jointly authored this submission, b) this work represents their original work, c) that they have not been provided with nor examined another person's assignment, either electronically or in hard copy, and d) that this work has not been previously submitted for academic credit.

LAB 4. PROPORTIONAL-INTEGRAL-DERIVATIVE CONTROLLER ANALYSIS

ASSIGNED DATA

For easily referencing it, the Assigned Data has been placed at the start of this document. To determine your assigned data, read Section 2 of this prelab.

On your pre-lab and post-lab submissions, always include this page at the beginning of the document.

Select your lab session:	morning lab; afternoon lab;					
	∑ Tue; ☐ Wed; ☐ Thu					
GroupNumber						
Assigned plant formula	GroupNumber - rounddown(GroupNumber/24.5, 0) * 24					
	(valid Excel formula syntax)					
Assigned plant number:	21					
P(s) parameters	On ACS-13005 $K_1 = 10$					
		a = 1				
	On ACS-13008 B = 2.5					
	$T_1 = 100$					
	On ACS-13007 $K_2 = 5$					
	On ACS-13006 $T_2 = 10$					

	M_p	y_{ss}	T_p
	(V)	(s)	(s)
Experimental	0.11	0.1	0.09
Simulated	0.11	0.1	0.08
Errors	0	0	0.18

Table 1: Plant verification results




Figure 1: Plant verification response

5.2

\mathbf{a}

The minimum value of K_p to cause instability was 5.55. This was determined by slowly increasing the gain until the response stopped converging.

K_p	T_p	M_p	y_{ss}	OS	e_{ss}	$T_s 2\%$
	(s)	(V)	(V)	%	%	(s)
1	0.09	0.11	0.1	14	50	0.19
2	0.08	0.17	0.13	33.08	35	0.23
3	0.07	0.21	0.14	44.44	28	0.36
4	0.055	0.24	0.16	54.84	22.5	0.4

Table 2: Measurements of P-controlled system

 \mathbf{c}

As K_p increases the first peak occurs faster and peaks higher. This results in an increase in overshoot. The steady-state error decreases at the cost of an increased settling time. This can also be seen in the increasing settling value.

 \mathbf{d}




Figure 2: Root locus of system under proportional control

\mathbf{e}

The height of the first peak is proportional to overshoot which is proportional to the angle from the origin to the poles. As can be seen on the root locus as K_p increases the angle of the poles increases which is why the height of the first peak and overshoot increase with K_p . The time to the first peak is inversely proportional the imaginary part of the pole. The root locus shows as K_p increases the imaginary part of the poles increases which corresponds to our time to first peak decreasing. The settling time is inversely proportional to the real part of the poles and as K_p increases the real part of the poles decreases causing the settling time to increase. The settling value increases since it is directly proportional to the gain which is K_p . The error is the difference between the input and steady-state value and we can see our steady-state value increasing towards the input as K_p increases so the error decrease with it. We can ignore the pole traveling along the real axis as it gets farther away from the imaginary axis allowing the other poles to dominate it.

\mathbf{f}

You can reduce your steady-state error by increasing K_p until steady-state value reaches the input value provided that it does not cause the system to become unstable. For our system we approach 8 and in a general case it can approach the value of K_p where the root locus crosses the imaginary axis.

5.3

a

K_i	T_p	M_p	y_{ss}	OS	e_{ss}	$T_s2\%$
30	0.1	0.24	0.2	21.5	0	0.3
40	0.1	0.27	0.2	35	0	0.5
50	0.09	0.3	0.2	50	0	0.73
60	0.085	0.33	0.2	65	0	1.08

Table 3: Measurements of PI-controlled system




Figure 3: P-I controlled system response

b

As K_i increased the height of the first peak and the overshoot increased. The steady-state value stayed equal to the input value resulting in no error regardless of K_i . The time to first peak plateaued then decreased and the settling time increased as K_i increased.




Figure 4: Root locus of P-I controlled system

\mathbf{d}

The height of the first peak and overshoot are is proportional to the angle of the poles. As K_i increases the angle of the poles increases which is why the height of the first peak and overshoot increase with K_i . The settling value increases since it is directly proportional to the gain which is K_p and this did not change. Similarly the error did not change. The time to the first peak is inversely proportional the imaginary part of the pole. The root locus shows as K_i increases the imaginary part of the poles bowls for a short bit then increases which corresponds to our time to first peak recordings. The settling time is inversely proportional to the real part of the poles and as K_i increases the real part of the poles decreases causing the settling time to increase. We can ignore the two branches of the root locus heading to infinity as these are quickly dominated by the other two branches.

a

K_d	T_p	M_p	y_{ss}	OS	e_{ss}	$T_s 2\%$
0	0.09	0.1	0.1	0	50	0.24
0.33	0.05	0.1	0.1	0	50	0.1
0.66	0.14	0.1	0.1	0	50	0.14
0.1	0.18	0.1	0.1	0	50	0.18

Table 4: Measurements of PD-controlled system




Figure 5: P-D controlled system response

b

As K_d increases the time to first peak dips slightly then increases. The value of the first peak slightly decreases and the settling value remains roughly the same. The overshoot also remained the same. The steady-state error remains roughly the same and the settling time dips and then increases.




Figure 6: Root locus of P-D controlled system

\mathbf{d}

The time to the first peak dips while the imaginary poles are dominating due to their imaginary parts increasing (it has an inverse relationship), but begins to rise as the real pole starts dominating. The same can be said for the settling time which is inversely proportional to the real part of the poles causing it to decrease while the complex poles dominate and increase when the real pole starts dominating. The overshoot is zero for all values due to the angle of the poles being very small while the complex poles dominated (likely due to rounding errors when reading these values) and then dropping to zero when the real pole dominates. This same logic applies to why the height of the first peak remains roughly the same. The settling value is proportional to K_p which remained constant keeping it constant. This also resulted in the steady-state error remaining constant as neither the input nor steady-state value changed.

5.5

a

K_p	K_i	K_d	T_p	M_p	y_{ss}	OS	e_{ss}	$T_s 2\%$
1	25.2	0.02	0.13	0.2	0.2	0	0	0.13

Table 5: PID controlled system

b

Increasing K_i by large amounts eliminated the steady-state error, but increased the overshoot. Adding in K_d eliminated the overshoot without increasing the settling time excessively. Together they produced a stable system that responded quickly.

\mathbf{c}

To improve the steady-state performance of our system you only need to add integral action.